

7343 J. Ronson Rd. San Diego, CA 92111 [714] 571-6971



2 92931

SHUGART MODEL 851 JUMPERING

The following jumpering is required for operation with the ZOBEX DD controller board for Shugart Model 850 and 851 drives.

	JUMPER	LOCATION 392938	STATUS		300386
	M	VB-5	IN		F
	RM	VC-4 V	IN		
	RS	C-4	OUT		
	HLL	VC-5.1	OUT		
	DL	VC-5-	OUT	~	
	Y	~C-5-	OUT		
	NP	€C-6	OUT		
	WP	1C-64	IN		
	D5	12D-4	OUT		
MFN	AF	D-7	IN		
Mapon	NF	VD-7	OUT		
	D	E-4	OUT		
	C	VE-4	IN		
	Sl	VE-5	OUT		
	S2	VE-5	IN		
	S3	E-5	OUT		
	R-PACK	E-5.	IN ON	LAST DRIVE ONLY	
	IT	VE-6 W	IN		
	IW	WF-3 -	PUUT	(SHORT AXIS- NOT GRO	UNDED)
	FS	VF-8.	IN	(LONG AXIS)	
	TS	F-8	OUT		
	851	VF-2V	OUT		
	850	VF-2V	IN		
	RI	F-3	IN		
	RR	vF-3 v	IN		
	2S	F-3	IN		
	DC	VF-3 V	IN		
	Z	VF-4	IN		
	HL	VF-4	IN		
	A	WF-4	IN		
	В	VF-4 V	IN		
	X	VF-4	OUT		
	I	¥F-4	IN		
	R	VF-4 V	IN		
	S	VF-4	OUT		
	DS1	₹-5¥	TO 1B	IF DRIVE A, ELSE OU	T
	DS2	√F-5 √		IF DRIVE B, ELSE OU	
	DS3	VF-5	OUT		
	DS4	₩F-5₩	OUT		



7343 J. Ronson Rd. San Diego, CA 92111 [714] 571-6971

JUMPER DOCUMENTATION FOR SHUGART 800 DRIVES

T3, T4, T5, T6 T2	SHORT
T1	SHORT
DS1 or DS2	SHORT
RR	SHORT
Rl	SHORT
R,I,S	SHORT
A,B	SHORT
X	OPEN
HL	SHORT
DS	OPEN
WP	SHORT
NP	OPEN
D	OPEN
2,4,6,8,10,12,14,16,18	OPEN
D1,D2,D4,DDS	OPEN
C	SHORT
Z	SHORT
Y	OPEN
DC	SHORT
800	SHORT

Note:

ON DRIVE "B" REMOVE : T1, T3, T4, T5, T6